

HISTORIC WALL PANELLING INSTALLATION GUIDELINES

Installer responsibility: READ CAREFULLY PRIOR TO INSTALLATION

Installation Conditions:

The most ideal room and wall temperature on the installation site should be controlled around 18 degrees, a temperature surrounding below 15 degrees or more than 35 degrees with an air humidity 45-75% will not be a suitable condition for installations to take place.

Acclimatisation:

The packs should be stored horizontally in the room that is being fitted for at least 72 hours before installation - the longer the better. All structural work, in particular any cement, plaster and painting work should be completed and dry before panelling is left to acclimatise.

Wall Requirements:

- 1.** The wall must be hard, smooth, dry and strong.
 - 2.** The wall surface must be levelled; use sandpaper to fully level / smooth the surface.
 - 3.** The walls should be naturally dried or heat dried, the moisture content must be controlled below 5%.
 - 4.** The internal and external corners of the wall must also be smooth.
-

Installation:

FOR FULL INSTALLATION INSTRUCTIONS PLEASE CONTACT YOUR
LOCAL SUPPLIER OR DOWNLOAD ON WWW.WRG.IE